



**NOTE: HOLDERS ARE MADE FROM 1/2" DIA. BAR.
RUNNERS ARE MADE FROM 1 1/2" X 1 1/2" X 3/16" ANGLE
ALL PARTS ARE HOT DIP GALVANIZED AFTER FABRICATION**

ASSEMBLY INSTRUCTIONS:

1. Attach bike rack holders (A) to angle runners (B) using 5/16" x 1" bolts (D).
2. Depending on surface that the bike rack is installed upon, the proper anchors must be installed. If on concrete, use self setting anchors. If on asphalt, it is recommended that a footing of 6" dia x 10" deep be installed at each anchor hole.

(Anchors are not provided by L. A. Steelcraft)

| MODEL | HOLDERS [A] | RUNNER [B] | LENGTH | ANCHORS [C] | BOLT ASSY [D] | WIDTH | HEIGHT |
|-------|----------------|---------------|--------|----------------|------------------|---------|---------|
| BAX-2 | 2 | 2 | 19" | 2 | 4 | 19-3/4" | 20-1/4" |
| BAX-5 | 5 | 2 | 67" | 4 | 10 | 19-3/4" | 20-1/4" |
| BAX-8 | 8 | 2 | 115" | 4 | 16 | 19-3/4" | 20-1/4" |
| BA-4 | 4 | 2 | 27" | 2 | 8 | 22" | 20-1/4" |
| BA-5 | 5 | 2 | 35" | 4 | 10 | 22" | 20-1/4" |
| BA-9 | 9 | 2 | 67" | 4 | 18 | 22" | 20-1/4" |
| BA-15 | 15 | 2 | 115" | 4 | 30 | 22" | 20-1/4" |

NOTE: SPECIFICATIONS ARE SUBJECT TO CHANGE