



5/16" wide x 4" long – USA – Commercial

This is a large end 5/16" x 4" S-hook. This works with all our chains. Our commercial quality large end Shooks are designed to fasten chain to swing hangers and swing seats to help prevent binding. They are plated to help resist rust. Tensile strength 745 lbs.

Installation:

Make sure you are using correct size of S-hook. Closing S-hook should not crimp material producing a wear spot on whatever material you are attaching to S-hook. If this occurs, use a larger S-hook to extend life of product. Because S-hooks are often constructed of heavy-duty materials that can withstand significant weight, they are not easy to close. A pair of pliers designed for closing and opening S-hooks, such as our LA-T-100 is necessary. To close S-hooks: Put the S-hook in the front part of the large jaws and close the pliers' legs and the S-hook will close. Make sure all S-hooks are closed to within .04 to meet ASTM safety standards. To open S-hooks: Use the little jaws at the other end of the pliers' head. Put the top or outer jaw inside of the closed S-hook. Close the pliers' legs and the S-hook should open. WARNING: Once the S-hooks have been opened they will have to be replaced to avoid injuries from coming open and/or breaking

Maintenance: At beginning and end of each play season and once a month during play season, check for sharp edges and/or cracks in metal. Check for excessive wear. Replace parts as necessary for safety. Make sure S-hooks are closed to within .04 to meet ASTM safety standards. Check for vandalism. Maintain detailed inspection and maintenance records for public-use playground equipment. Any damage from vandalism, abuse or misuse VOIDS all warranties.